

Model: BPB180

Model Description: CORDLESS PORTABLE BAND SAW

Item	Sub	Sub_Expl anation	Parts_No.	Parts_Description	Qty	Unit
001			922456-6	HEX. SOCKET HEAD BOLT M8X35	2	PC.
002			941202-8	FLAT WASHER 8	2	PC.
003			273525-9	GRIP	1	PC.
004			210033-9	BALL BEARING 696ZZ	1	PC.
005			256033-5	PIN 6	1	PC.
006			265999-8	TAPPING SCREW 4X25	2	PC.
007			266147-2	TAPPING SCREW 4X55	2	PC.
008			272223-2	LEVER 60	1	PC.
009			267041-1	FLAT WASHER 20	1	PC.
010-1			158703-1	FRONT WHEEL COVER COMPLETE	1	PC.
010-1	C10		816212-3	INDICATIONAL LABEL	1	PC.
011			210033-9	BALL BEARING 696ZZ	1	PC.
012			941152-7	FLAT WASHER 6	1	PC.
013			210033-9	BALL BEARING 696ZZ	1	PC.
014			251337-0	+ PAN HEAD SCREW M7	1	PC.
015			317824-0	UPPER HOLDER	1	PC.
016			266034-5	TAPPING SCREW CT 4X16	2	PC.
017			256033-5	PIN 6	1	PC.
018			210033-9	BALL BEARING 696ZZ	1	PC.
019			343494-9	SLEEVE 5	1	PC.
020			163276-1	SLIDE PLATE	1	PC.
021			231449-5	COMPRESSION SPRING 11	1	PC.
022			210033-9	BALL BEARING 696ZZ	1	PC.
023			941152-7	FLAT WASHER 6	1	PC.
024			210033-9	BALL BEARING 696ZZ	1	PC.
025			251337-0	+ PAN HEAD SCREW M7	1	PC.
026			343494-9	SLEEVE 5	3	PC.
027			941051-3	FLAT WASHER 4	3	PC.
028			266034-5	TAPPING SCREW CT 4X16	3	PC.
029			231449-5	COMPRESSION SPRING 11	1	PC.
030			343489-2	TENSION PLATE	1	PC.
031			911221-8	PAN HEAD SCREW M5X16	1	PC.
032			421333-4	RUBBER TIRE	1	PC.
033			253749-3	FLAT WASHER 16	1	PC.
034			152325-9	WHEEL COMPLETE	1	PC.
035			253749-3	FLAT WASHER 16	1	PC.
036			253010-8	FLAT WASHER 6	1	PC.
037			922312-0	HEX. SOCKET HEAD BOLT M6X12	1	PC.
038			210033-9	BALL BEARING 696ZZ	1	PC.
039			941152-7	FLAT WASHER 6	1	PC.
040			210033-9	BALL BEARING 696ZZ	1	PC.
041			251337-0	+ PAN HEAD SCREW M7	1	PC.
042			251337-0	+ PAN HEAD SCREW M7	1	PC.
043			210033-9	BALL BEARING 696ZZ	1	PC.
044			941152-7	FLAT WASHER 6	1	PC.
045			210033-9	BALL BEARING 696ZZ	1	PC.
046			256033-5	PIN 6	1	PC.
047			210033-9	BALL BEARING 696ZZ	1	PC.

Model: BPB180

Model Description: CORDLESS PORTABLE BAND SAW

Item	Sub	Sub_Expl anation	Parts_No.	Parts_Description	Qty	Unit
048			317823-2	LOWER HOLDER	1	PC.
049			266034-5	TAPPING SCREW CT 4X16	2	PC.
050			418784-0	SAW GUARD HOLDER	1	PC.
051			266042-6	TAPPING SCREW BIND CT 4X20	2	PC.
052			421333-4	RUBBER TIRE	1	PC.
053			266021-4	TAPPING SCREW 5X20	3	PC.
054			154949-7	GEAR COMPLETE	1	PC.
055			419506-1	WHEEL	1	PC.
056			324513-0	LOWER SHAFT	1	PC.
057			253749-3	FLAT WASHER 16	1	PC.
058			253010-8	FLAT WASHER 6	1	PC.
059			922312-0	HEX. SOCKET HEAD BOLT M6X12	1	PC.
060			253749-3	FLAT WASHER 16	1	PC.
061			922323-5	HEX.SOCKET HEAD BOLT M6X16	1	PC.
062			266203-8	TAPPING SCREW BIND CT 4X40	1	PC.
063			266147-2	TAPPING SCREW 4X55	2	PC.
064			266048-4	TAPPING SCREW 4X40	2	PC.
065			317947-4	REAR WHEEL COVER	1	PC.
066			265995-6	TAPPING SCREW 4X18	8	PC.
067			265995-6	TAPPING SCREW 4X18	2	PC.
068			911243-8	PAN HEAD SCREW M5X25	2	PC.
069			188108-1	HANDLE SET	1	SET
069	D10	INC. 72		INC. 72	0	
070			911213-7	PAN HEAD SCREW M5X12	4	PC.
071			168412-4	REAR BUMPER	1	PC.
072			188108-1	HANDLE SET	1	SET
072	D10	INC. 69		INC. 69	0	
073			232201-4	LEAF SPRING	1	PC.
074			419504-5	LOCK OFF BUTTON	1	PC.
075			650229-4	SWITCH SGE120C-3	1	PC.
076			227170-2	SPUR GEAR 12	1	PC.
077			962203-3	RETAINING RING R-47	1	PC.
078			211306-3	BALL BEARING 6204LLB	1	PC.
079			227470-0	SPIRAL BEVEL GEAR 29	1	PC.
080			254202-2	KEY 4	1	PC.
081-1			210029-0	BALL BEARING 608ZZ	1	PC.
082			227481-5	SPIRAL BEVEL GEAR 11	1	PC.
083-1			211241-5	BALL BEARING 6202DDW	1	PC.
084			961055-9	RETAINING RING S-15	1	PC.
085			226626-2	HELICAL GEAR 45	1	PC.
086-1			210029-0	BALL BEARING 608ZZ	1	PC.
087			252157-5	SQUARE NUT M6	2	PC.
088			345467-8	STOPPER PLATE	1	PC.
089			251981-3	HEX. SOCKET HEAD BOLT M6X16	2	PC.
090			154475-6	GEAR HOUSING COMPLETE	1	PC.
091			619187-3	ARMATURE	1	PC.
094			638420-4	YOKE UNIT	1	PC.
094-1			638420-4	YOKE UNIT	1	PC.

Model: BPB180						
Model Description: CORDLESS PORTABLE BAND SAW						
Item	Sub	Sub_Expl anation	Parts_No.	Parts_Description	Qty	Unit
095-1			638919-9	ENDBELL COMPLETE	1	PC.
096			188107-3	HOUSING SET	1	SET
096	D10	INC. 97		INC. 97	0	
096-1			187801-4	HOUSING SET	1	SET
096-1	D10	INC. 97		INC. 97	0	
097			188107-3	HOUSING SET	1	SET
097	D10	INC. 96		INC. 96	0	
097-1			187801-4	HOUSING SET	1	SET
097-1	D10	INC. 96		INC. 96	0	
098			643929-3	BRUSH HOLDER CAP	2	PC.
099			191971-3	CARBON BRUSH CB-430	1	SET
100-1			638918-1	CONTROLLER UNIT	1	PC.
100-2			632B83-0	CONTROLLER UNIT	1	PC.
101			643812-4	TERMINAL	1	PC.
101-1			644808-8	TERMINAL	1	PC.
102			213261-5	O RING 17	1	PC.
103			419505-3	DIAL	1	PC.
104			862499-5	BPB180 NAME PLATE	1	PC.
106			168413-2	FRONT BUMPER	1	PC.
107			266042-6	TAPPING SCREW BIND CT 4X20	2	PC.
108			418784-0	SAW GUARD HOLDER	1	PC.
109			266034-5	TAPPING SCREW CT 4X16	1	PC.
110			345468-6	SAW GUARD	1	PC.
110-1			346669-9	SAW GUARD	1	PC.
A01-1			***DC18RC	DC18RC FAST CHARGER	1	PC.
A02-5			194204-5	BATTERY BL1830 SET	2	PC.
A02-6			194204-5	BATTERY BL1830 SET	2	PC.
A03-1			B-10350	BAND SAW BLADE 18 BIMETAL	1	PC.
A04			783202-0	HEX. WRENCH 4	1	PC.
A04A			783202-0	HEX. WRENCH 4	1	PC.
A05-1			141496-7	PLASTIC CARRYING CASE	1	PC.
A05-1	C10		163467-4	LATCH	2	PC.
A05-1	C20		819145-1	MAKITA LOGO LABEL	1	PC.
A06			450128-8	BATTERY COVER	1	PC.